


Though many garage doors are offered in standard sizes, ensuring your custom Timberlane garage door is sized specifically for your home is crucial throughout your designing experience. Below is our easy to use garage door measuring guide that quickly covers how to accurately record the measurements of your garage door opening.




Outside View

## Step 1: Garage Door Opening Width


Begin by measuring the width of your garage door opening. As shown to the left, this is the total distance between the inside edge of the right door trim to the inside edge of the left door trim.

## Step 2: Garage Door Opening Height

Next, measure the height of your garage door opening. This is the total distance between the inside edge of the top door trim to the garage floor.



Outside View




Inside View

## Step 3: Garage Door Sideroom


Next, you'll need to measure the distance between the side door openings and the ends of the garage space. This is done by measuring from the inside edge of the right and left door trims to each sidewall.

## Step 4: Garage Door Headroom

Continue by measuring the space between the top of the door opening to the ceiling or the lowest obstruction such as ceiling joists and beams.



Inside View



Inside View

## Step 5: Garage Door Backroom

Finally, measure the distance from the door opening to the rear of the garage or nearest obstruction that would interfere with normal door operation.

## Additional Items to Consider While Recording Measurements

- Verify the electrical outlet for the garage door opener (if this is for a new installation).
- Door framing must be made square and plumb. It must also be constructed using 2" x 6" framing.
- Note any additional obstructions such as light fixtures, ceiling fans, staircases, pipes, ductwork entry doors, etc.
- Verify all jamb materials are in good condition with no visual defects.
- Verify the floor is level.
- 2" x 8" framing and blocking must be located at the center of the opening to mount the torsion springs.

# Garage Door Measurements Cheat Sheet

Measuring is one of the first steps in getting your custom-made Timberlane garage door. Use a tape measure to collect your dimensions and record in the areas outlined below.

Date: \_\_\_\_/\_\_\_\_/\_\_\_\_


Email: \_\_\_\_\_

Name: \_\_\_\_\_

Phone: \_\_\_\_ - \_\_\_\_ - \_\_\_\_


Job Name: \_\_\_\_\_

Fax: \_\_\_\_ - \_\_\_\_ - \_\_\_\_



Door Type \_\_\_\_\_  
Opening Width \_\_\_\_\_  
Opening Height \_\_\_\_\_  
Sideroom \_\_\_\_\_  
Headroom \_\_\_\_\_  
Backroom \_\_\_\_\_

Door # \_\_\_\_\_




Door Type \_\_\_\_\_  
Opening Width \_\_\_\_\_  
Opening Height \_\_\_\_\_  
Sideroom \_\_\_\_\_  
Headroom \_\_\_\_\_  
Backroom \_\_\_\_\_

Door # \_\_\_\_\_



Door Type \_\_\_\_\_  
Opening Width \_\_\_\_\_  
Opening Height \_\_\_\_\_  
Sideroom \_\_\_\_\_  
Headroom \_\_\_\_\_  
Backroom \_\_\_\_\_

Door # \_\_\_\_\_



Door Type \_\_\_\_\_  
Opening Width \_\_\_\_\_  
Opening Height \_\_\_\_\_  
Sideroom \_\_\_\_\_  
Headroom \_\_\_\_\_  
Backroom \_\_\_\_\_

Door # \_\_\_\_\_

## Notes:

## READY TO SEND YOUR MEASUREMENTS?

We specialize in advising our customers through the process of designing garage doors for your home or project. For increased accuracy, please send photos of your garage door openings as well as the inside of your garage.

[EMAIL TODAY](#)